

HSA.SPLATE HOLOSAIR SCENE PLATE

INTERIOR LIGHTING CONTROLS

OVERVIEW

Standard 6 button scene plate.

installation

The scene plate can be installed with a standard one-gang back box in combination with a Holos Air wireless scene node HSA.NODE.SW.

The scene plate allows for an elegant and flexible solution for Holos Air enabled systems.

It contains all the necessary contacts that are required with a HSA.NODE.SW to provide scene setting or an override function.

There is no need for an external power supply as there is a direct connection to the wireless node via a 6-core cable.

The contacts are normally open (NO) and have a push button function.

commissioning

The scene plate must be commissioned in combination with the respective HSA.NODE.SW. There are no programmable parts in the scene plate itself.


inputs

- 6-core wired connection to a HSA.NODE.SW wireless scene controller with a CAT5 or other cable (max diameter up to 1.5mm²).

features

- Brushed steel metal scene plate.
- Used to recall scenes which have been programmed using the tablet application.
- To be used in association with a mains or battery powered Scene Controller.

Note: Keep push button lead length as short as possible and no more than 3m. Lead length can be extended by up to 200m by using Optoisolate Option. Contact Holophane for further information.



HOLOS*Air*

Holophane Europe Limited, Bond Avenue, Bletchley, Milton Keynes MK1 1JG United Kingdom
Telephone: +44 (0)1908 649292 UK Fax: +44 (0)1908 367618 International Fax: +44 (0)1908 363789
E-mail: info@holophane.co.uk www.holophane.co.uk

February 2023


HOLOPHANE[®]
An Acuity Brands Company